ORCA Control Panel

The ORCA Control Panel allows editing of settings and values in each menu.

Two line LCD Display

Pump RUN Indicator

Pump Enable Indicator

Pump Enable button

Input Indicators

Each pump is controlled by an individual "P" button.

The **Access Code** is required to **enable**, or **manually** run a pump.
Pumps can be stopped and disabled without an Access Code.
The Default Code is 21

To enable a pump for operation
Press the "P" button and the associated mode indicator will light up. The selected pump is now **available** for operation in **Automatic** mode.

To disable a pump in Automatic Mode
Press the "P" button until the Pump ON/OFF indicator light turns off.

Manual Operation
Press and hold the "P" switch for 3 seconds to start a pump in "Manual".

The Pump ON/OFF indicator light will be flashing and the RUN indicator will be on. To turn a manual pump off, press and release the "P" switch.
The RUN light turns off when the pump is disabled.
To return it to Automatic press the "P" button again until the Mode indicator turns on.