



SNAPPER+ VFD SETTINGS

VACON 100

'Quick Edit'	Parameters	Description	Vacon Default	Snapper+ Set-up
		Startup Wizard	Standard	Standard
103	M1.5	Acceleration Time	5 Second	1 Second
104	M1.6	Deceleration Time	5 Second	1 Second
107	M1.7	Current Limit	I _L	Motor Name Plate +10%
110	M1.9	Nominal Motor Voltage	230/400V	Motor Name Plate
111	M1.10	Nominal Motor Frequency	50.00Hz	Motor Name Plate
112	M1.11	Nominal Motor Speed	1440	Motor Name Plate
113	M1.12	Nominal Motor Current	I _L	Motor Name Plate
300	P3.2.6	I/O A Start/Stop Logic	Forw-Back (Edge)	Forw-Back
379	M1.25	A11 Signal Range	0V-10V/0-20mA	0V-10V/0-20mA
11001	P1.27	Relay Output 1 Function	Ready	Fault

TO RESET VACON 100-FLOW TO FACTORY DEFAULTS:

- 1, Press function button
- 2, Select quick edit
- 3, Type in 831
- 4, Default should be [0], Change to [1] to reset to default.